



×



COLLECTOR MODEL
1:10 SCALE RC

USER GUIDE



14+





Congratulations on unlocking a cutting-edge Hot Wheels® RC experience that propels you into a new dimension of performance and possibilities. With their California roots, Hot Wheels® and Tesla have a rich history of creating revolutionary vehicles, and this RC Cybertruck is no exception—it's a powerhouse pickup that combines speed, sleekness, and strength rolled into one. Aside from armor glass, what records will you shatter? (Steel ball not included.)

⚠ CAUTION:

Surfaces may become hot and cause burns if electronics get wet. To prevent entanglement, keep all hair away from moving parts.

Keep these instructions for future reference as they contain important information.

IMPORTANT: Please read all instructions before operating your vehicle.


Adult supervision is recommended when the vehicle is being operated.

1: CONTENTS



CRACKED WINDOW STICKERS

REMOTE CONTROLLER





4 SCREWS




BUMPER GUARD




WALL CHARGER



VEHICLE





BATTERY PACK



ADAPTER


2: FEATURES



3: SET UP

A. REMOTE CONTROLLER BATTERY INSTALLATION

1. Slide open the battery cover.
2. Install 4 AA (LR6) alkaline batteries (not included) with polarity (+/-) as shown inside the battery compartment. For longer life, use alkaline batteries.
3. Slide the battery cover back on the remote controller.
4. Replace batteries in the remote controller if the vehicle does not respond well after a recharge or if you see a red light flashing in the LED indicator during play.




B. CHARGING THE VEHICLE

The vehicle is powered by a Lithium-ion (Li-ion) battery pack, and it must be fully charged with the included wall charger before first use.

1. Plug the wall charger into a standard wall outlet.
2. Connect the battery pack's charger connector to one end of the adapter. Connect the other end of the adapter to the wall charger to begin charging. Make sure the connectors are tightly attached.
3. A red LED will light up on the wall charger to indicate the battery pack is charging. Green LEDs will also light up on the adapter to indicate the battery charge level. Charging is complete when the wall charger LED turns green or when the green LEDs on the adapter reach 100%. A full charge will take approximately 60 minutes. Charging time may vary.

4. To disconnect the wires, push down on the connector clip and pull apart.
5. Unlike alkaline batteries, where the power loss is gradual, a Li-ion battery will run for its normal running time (approximately 10 to 30 minutes depending on driving style and mode) and then lose most of its power at once. It is now time to recharge the battery.




TIPS:

- Charging the battery for more than what is recommended will not give you a longer running time.
- The battery will be hot after play. Wait at least 10 to 15 minutes until the battery cools down before recharging the battery.
- When red LEDs light up on the adapter, you should unplug the charger connectors from both ends of the adapter. Wait at least 10 minutes until the battery and adapter resume normal operation before charging the battery again.



C. INSTALLING THE BATTERY PACK

1. Unscrew the vehicle's battery box cover with a flat head screwdriver (not included).
2. Connect the battery pack's vehicle connector to the vehicle's battery connector.
3. Make sure the connectors are tightly attached and close the battery box cover.



IMPORTANT!

- Turn off the vehicle after play. Leaving a discharged battery pack in a vehicle for a prolonged period of time can severely damage the battery. Always charge the battery prior to storage.
- As a reminder to switch the vehicle OFF after play, the front wheels will suddenly move left and right if left idle for a few minutes with the power still switched on.

D. PAIRING THE REMOTE CONTROLLER AND VEHICLE


1. Slide the ON/OFF switch to I (ON) on the remote controller, and a green LED will light up if there is sufficient battery power.
2. Slide the ON/OFF switch to I (ON) on the vehicle to complete the pairing process.
3. If the vehicle does not respond to the remote controller, turn the vehicle and remote controller OFF then ON to try pairing them again.

E. THROTTLE/STEERING TRIM

It's recommended that you check the vehicle's throttle and steering alignment before play.


THROTTLE TRIM

1. Press and release the throttle trigger.
2. If the vehicle continues to move forward after the throttle trigger is released, turn the throttle trim dial clockwise or counterclockwise until it stops.



STEERING TRIM

1. Drive the vehicle forward to see if it is driving straight.
2. If the vehicle automatically steers toward the right/left, turn the alignment trim dial to the opposite direction until the vehicle goes in a straight line.



F. THROTTLE/STEERING REVERSING

Slide the switches to the other side to reverse the direction of the steering wheel and throttle trigger.

G. ATV (ADJUSTABLE TRAVEL VOLUME)

Turn the dial to adjust the maximum steering angle of the vehicle when it turns left or right.

ATTENTION DRIVER!





It's highly recommended that you install the bumper guard for extra protection as you learn the capabilities of the vehicle.

H. INSTALLING THE BUMPER GUARD

Install the bumper guard with a Phillips head screwdriver (not included) for additional protection to the vehicle.

I. REATTACHING THE TAILGATE TETHERS

To reattach the tailgate tethers, insert them into the tailgate pegs and then rotate to lock them in place.



4: HOW TO DRIVE

CHECKLIST


- Is the vehicle's battery box door closed properly?
- Is the vehicle's battery pack fully charged?
- Is the remote controller equipped with fresh batteries?
- Is the remote controller paired with the vehicle?
- Has the vehicle's throttle and steering been trimmed?

CONTROLS


Use the throttle trigger to drive forward and backward. Rotate the steering wheel as the Cybertruck is moving to turn left/right.

NOTE: Operating range of the remote controller is up to 100 ft (30 m).


Forward




Backward



Turn Left



Turn Right



SKILL CHECK!

Remember, turning directions are flipped on the remote controller when you are driving backward!

SPEED MODES


The Cybertruck is equipped with two speed modes: CHILL MODE and SPORT MODE.

Chill Mode is the default speed mode your vehicle is in once it is switched on. Sport Mode, on the other hand, increases the vehicle's throttle power and allows for a higher speed.

To switch to Sport Mode, press and hold the Speed Mode button for approximately 5 seconds. The remote controller's LED will flash quickly to indicate the vehicle is in Sport Mode. To switch back to Chill Mode, press and hold the Speed Mode button again for approximately 5 seconds or switch the remote controller and vehicle OFF then back ON so it returns to the default speed mode.

NOTES:

- Speed modes cannot be switched when the vehicle is in motion. Stop the vehicle and wait until it is still before switching modes.
- The vehicle will consume more battery power when it is in Sport Mode.



5: CONSUMER INFORMATION



TIPS & HINTS – FOR ALL DRIVING ENVIRONMENTS

1. When your vehicle starts to lose power, it may lose functions or performance. It's time for a recharge. For best performance, always start with a fully-charged battery. Your vehicle's running time may change depending on driving style and driving environment.
2. Radio interference can make your vehicle run badly. Interference can be caused by other RC vehicles running on the same frequency, electrical wires, large buildings, CB radios, or other wireless gear. Try to stay away from these!
3. Point your remote controller up, and not down toward your vehicle. If your vehicle gets too far away, it won't work properly.
4. Don't store your vehicle near heat or in direct sunlight. Always turn switches OFF and remove all batteries from the remote controller before storage.
5. Don't drive your vehicle in sand or through water or snow. Do not immerse in water. If your vehicle does get wet, wipe it with a towel and allow to dry completely overnight. If your remote controller is accidentally dropped in water, remove battery(ies) and allow your remote controller to air-dry. Replace with fresh battery(ies) before operation.
6. When exposed to an electrostatic source, the remote controller and/or the vehicle may malfunction. To resume normal operation of the remote controller, remove the batteries and reinstall them after 5 seconds. To resume normal operation of the vehicle, turn the power OFF for 5 seconds, then turn it ON again.
7. For extended storage, make sure to charge the battery before storing so that the battery does not become depleted over time. The battery should be charged once a year if the vehicle is to remain in storage.

SAFETY TIPS

- Play safely! Do not drive the vehicle in the street!
- DO NOT pick up the vehicle while in motion.
- Keep fingers, hair, and loose clothing away from the wheels while the vehicle is switched ON.
- Adult supervision is recommended when this vehicle is being operated.
- To avoid accidental operation, remove all batteries from the remote controller when not in use and switch the vehicle OFF before storage.

RECHARGEABLE BATTERY SAFETY INFORMATION

- Rechargeable batteries are only to be charged under adult supervision.
- Do not recharge the battery if it is hot. Allow it to cool before recharging.
- Do not recharge a battery pack that shows leakage or corrosion.
- Do not disassemble the battery pack. The battery pack is a sealed rechargeable Li-ion battery pack.
- If the battery pack and/or charging port are wet, thoroughly dry before charging.
- Do not recharge non-rechargeable batteries.
- The Li-ion battery in the vehicle is not intended to be replaced or removed by consumers. Before disposal in the waste stream, the Li-ion battery must be removed by a qualified professional and disposed of separately according to local regulations on battery collection and recycling.
- Do not dispose of the batteries in a fire.
- Rechargeable batteries are to be recharged with the charger included in the package.
- Rechargeable batteries should be fully charged before placing in storage. Do not store depleted batteries.



BATTERY SAFETY INFORMATION

In exceptional circumstances, batteries may leak fluids that can cause a chemical burn injury or ruin your product. To avoid battery leakage:

- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Do not mix old and new batteries.
- Only batteries of the same or equivalent type as recommended are to be used.

- Batteries are to be inserted with the correct polarity (+ and -).
- Exhausted batteries are to be removed from the product.
- The supply terminals are not to be short-circuited.
- Dispose of battery(ies) safely.
- Do not dispose of this product in a fire. The batteries inside may explode or leak.

FOR PRODUCT SOLD IN USA

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

NOTE: Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

FCC ID: YDTCTX-8000JP



Protect the environment by not disposing of this product or any batteries with household waste. This symbol indicates that this product shall not be treated as household waste. Check your local authority for recycling advice and facilities.



©2020 Mattel. ® and ™ designate U.S. trademarks of Mattel, except as noted. Mattel, Inc., 636 Girard Avenue, East Aurora, NY 14052, U.S.A. Consumer Services 1-800-524-8697. Mattel U.K. Limited, The Porter Building, 1 Brunel Way, Slough SL1 1FQ, UK. Mattel Australia Pty. Ltd., 658 Church St., Richmond, Victoria, 3121. Consumer Advisory Service - 1300 135 312. Mattel South Africa (PTY) LTD, Office 102 I3, 30 Melrose Boulevard, Johannesburg 2196. Mattel East Asia Ltd., Room 503-09, North Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China. Tel.: (852) 3185-6500. Diimport & Diedarkan Oleh: Mattel Continental Asia Sdn Bhd. Level 19, Tower 3, Avenue 7, No. 8 Jalan Kerinchi, Bangsar South, 59200 Kuala Lumpur, Malaysia.

Tesla, Inc., Cybertruck, and all related marks and emblems are intellectual property rights of Tesla, Inc. used under license to Mattel, Inc.



HOTWHEELS.COM



GXG31-0970_DOM